

Mikrotik Stup

Hosting Internal server

IP > Firewall > NAT : We can specify our own server for external access.

- 8181 - This is to MAC mini server Time log and mSupply registration page.
- 5900 -- This is to MAC mini screenshare
- 9100 -- This is to the label printer 192.168.3.246 for Moneyworks staff to do some label printing

NAT list

#	Action	Chain	Src. Address	Dst. Address	Prot...	Src. Port	Dst. Port	Any. Port	In. Interf...	Out. Interf...	In. Interf...	Out. Interf...	Src. Address List	Dst. Address List	Bytes	Packets
1	dst-nat	dstnat			6 (tcp)		8181		ether1						3645.1 KiB	63
2	dst-nat	dstnat			6 (tcp)		5900		ether1						49.9 MiB	875
3	dst-nat	dstnat			6 (tcp)		9100		ether1						172.3 KiB	3
4	src-nat	srcnat			6 (tcp)		3905		ether1						0.0	0
5	src-nat	srcnat			6 (tcp)		8282		ether1						0.0	0
6	src-nat	srcnat			6 (tcp)		3900		ether1						374.9 KiB	8.967

Setting for port 8181

NAT Rule

Enabled ☒

Chain: **dstnat**

Src. Address:

Dst. Address:

Protocol: **6 (tcp)**

Src. Port:

Dst. Port: **8181**

Any. Port:

In. Interface: **ether1**

Out. Interface:

In. Interface List:

Out. Interface List:


Packet Mark:

Connection Mark:

Routing Mark:

Routing Table:

Connection Type:



Domain re-direct

IP > DNS > Static button

- We can re-point ktm.msupply.org to our mac mini server : 192.168.3.200

DHCP Server

- IP > DHCP Server > Lease : We can lease IP address to a hardware

From:
<https://wiki.sussol.net/> - Sussol Internal Wiki

Permanent link:
https://wiki.sussol.net/doku.php/misc:hardware:sussol_hardware:mikrotik:hosting_internal_servers?rev=1745518965

Last update: 2025/04/24 18:22

